12L WHEELED SPRAYER GREEN Item codes: G330 Instructions for Use v002: 25/01/24

Please read and retain these instructions for future reference





Image is illustration only

STORAGE INSTRUCTIONS:

- Store out of direct sunlight and ensure the sprayer is empty.
- This is not a toy, keep out of reach of children especially when chemicals have been sued.

DISPOSAL

- Dispose of all packaging, paper, cartons, plastic and plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.



PARTS: Handle Sprayed body Lance

First insert the handlebar into the slots on the sprayer body and secure in place using the screw collar. Insert the lance into the connector at the end of the hose and secure with the screw collar.

INSTRUCTIONS FOR USE:

Fill the sprayer with the intended liquid, taking care to read the manufacturer's safety and usage guides for the chemicals. Pump the handle on top of the sprayer vigorously until the pressure builds up inside and the handle becomes more difficult to pump.

Repeat this process when necessary.

The trigger can be pushed forward to have continuous spraying, and the nozzle is adjustable from fine spray to jet.

To release any remaining pressure when finished, pull the valve out at the front of the sprayer.

CLEANING INSTRUCTIONS:

Clean the sprayer out with fresh water, any residual liquid must be disposed of according to local by-laws and regulations.

Make sure you rinse out the sprayer, pump unit and lance a number of times if you are going to change the chemical used, i.e. weed killer to plant feed.

CUSTOMER SERVICES:

Distributed by / Verteilt durch / Distribué par.

UK: The Enterprise Department Ltd. 11 Bridge Street, Bishops Stortford, Herts, UK, CM23 2JU Tel: 0330 331 0300

NI/EU: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269