Vibration Foot Massager

K626 v02: 13/06/22

Please read and retain these instructions for future reference





2x AA Batteries required (not included)

Dimensions

(W) 30 x (D) 6 x (L) 30cm

- SOOTHE COLD, TIRED AND ACHING FEET WITH A WARMING FOOT MASSAGE
- RELIEVE TIRED ACHING MUSCLES
- KEEP FEET WARM AND TREAT THEM TO A GENTLE MASSAGE
- SOFT FOAM CUSHION WITH 2 GENEROUS SIZED PLUSH POCKETS FOR YOUR FEET
- 2 SPEED VIBRATION MODES, CHOOSE THE RIGHT AMOUNT OF RELIEF FOR YOU
- SIMPLE ON OFF SWITCH
- FOAM FILLING, FLEECE OUTER

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

ALWAYS USE ALKALINE BATTERIES.

DO NOT USE LITHIUM BATTERIES.

Battery installation

(2x AA batteries are required – not included)

- Locate the battery compartment by unzipping the pillow cover.
- Slide off the cover of the battery compartment.

Note: Use caution not to damage the wire connectors.

- Insert 2x AA batteries, making sure to follow the polarity diagram imprinted on the inside of the battery compartment.
- Replace the compartment cover.
- Zip pillow cover.

Using your Vibration Foot Massager

- Position the pillow on the floor.
- Insert your feet into the left and right foot pocket located on the top of the pillow.
- Turn the pillow on by pressing the power/mode button on the left side of the pillow. There are 2 different modes I and II.
- Turn unit off after use.



Vibration Foot Massager к626

Instructions for Use

Please read and retain these instructions for future reference

v002: 13/06/22

Warnings

- Do not immerse the unit in water, as this will cause damage to the electrical components inside.
- Always supervise children while they are using this pillow.
- Only use as intended.
- Only use high quality alkaline batteries. Replace batteries when vibration gets weak.
- The unit is not intended to be used for treatment of any medical condition.

CLEANING

Spot clean only

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



Plastics, polybags – Contains the following recyclable plastic.

Code & Symbol	OTHER OTHER
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



The Enterprise UK Head Office, 11 Bridge Street, Bisho Tel: 0330 331 0300 Fax: 01279 756595 Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269