Microwave Lidded Bacon Crisper

K636 v01: 23/02/22

Please read and retain these instructions for future reference





Dimensions

(H) 6.8 x (W) 24.5 x (L) 27.5cm Material: 100% Polypropylene

- QUICK AND EASY WAY TO COOK BACON
- COOKS UP TO 5 PERFECT CRISPY BACON RASHERS AT ONCE
- SAVE MONEY NO NEED TO USE YOUR HOB
- NO SPITTING THANKS TO THE PROTECTIVE LID
- KEEPS YOUR MICROWAVE CLEAN AND GREASE-FREE
- EASY TO WASH, ANY EXCESS FAT JUICE IS EASILY DRAINED
- DISHWASHER SAFE

WARNING: PRODUCT WILL GET HOT DURING USE. ALWAYS WEAR OVEN GLOVES.

User instructions

Cooking times will vary based on Microwave Power, Thickness of bacon and preferred crispness

- Remove any excess fat from bacon.
- Lay the bacon on the tray, cover and place tray in the microwave.
- Microwave on high for 3 minutes. Then check the bacon. Continue to cook in 30 second bursts until bacon has cooked to preferred crispness

Cleaning and Maintenance

- Wash in soapy water before first use
- Dishwasher safe
- Dry thoroughly before storing
- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Hand wash in warm, soapy water, rinse and towel dry. Do not clean with metal pads, steel wool or abrasive cleaners.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



- Plastics, polybags Contains the following recyclable plastic. P
- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400*, Fax: 01279 756595 <u>www.coopersofstortford.co.uk</u> EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269 *UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.