




Folding Magnifying Glass



Thank you for purchasing our Foldable Magnifier with LED, with x5 x10 and x20 magnification.

We hope you are happy with your purchase.



Features:

- 3 levels of magnification: x10, x15 and x20.
- Blue LED light function for fake currency detection.
- 180° rotating handle for easy use.
- Light and compact for convenient storage and transport.

Instructions for flat objects:


- Press the power button located on the handle (as seen in the diagram above) once for the white LED function.
- Pull out the optical lens to the magnification level needed as marked in the diagram below.
- Press the power button twice to turn the magnifier off.

Instructions for irregular objects:

- Remove the transparent cover from the bottom of the magnifier.
- Press the power button located on the handle (as seen in the diagram above) once for the white LED function.
- Press the power button twice to turn the magnifier off.

Instructions for detection:


- Press the power button located on the handle (as seen in the diagram above) twice for the purple LED function.
- Place flat on the surface and extend the optical lens as needed.
- Press the power button once to turn the magnifier off.



- For all uses the light functions will work with the handle extended and closed.

Battery Replacement:

- To replace the batteries, unscrew the case at the back of the handle and remove the old batteries (see diagram below).
- Insert 4 x 4LR1130 batteries.
- Replace the battery cover.



4LR1130 batteries

Warning:

- Remove the batteries if not in use for a long period of time.
- Wipe clean using a soft cotton cloth to avoid damaging the lens.
- Do not place the magnifying glass in direct sunlight to avoid fire risk.
- Do not use the magnifying glass to look directly at the sun.

Battery Warning:

Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (including hydride)

Do not mix old and new batteries

Exhausted batteries are to be removed

The supply terminals are not to be short-circuited

Only batteries of the same or equivalent type as recommended are to be used

Batteries are to be inserted with the correct polarity

Battery Disposal:

The wheellie bin symbol indicates the product and batteries must not be disposed of in the domestic waste as they can contain substances that are damaging to the environment. Please use designated collection points or recycling facilities when disposing of the item or batteries. Batteries should be removed from the product. Contact your local waste disposal agency or your retailer for further information



Product Code: P222346

Made in China for S&S Enterprises Ltd. 26 Perivale Park Middlesex UB6 7RL

