Express Pasta Cooker

K704 v01: 16/03/22

Please read and retain these instructions for future reference





Dimensions (H) 31.5 x (D) 31.5cm

- SAFE, QUICK AND EASY PASTA COOKING
- AVOID HEAVY PANS AND RISK OF SCALDING WHEN DRAINING
- USES THERMAL CONDUCTIVITY TO COOK
- SIMPLY PUT THE WATER AND PASTA IN AND IT WILL BE READY IN 2-3 MINUTES
- USE LESS ENERGY AND SAVE MONEY
- DOESN'T JUST COOK PASTA. USE IT TO COOK PEAS, BROCCOLI AND OTHER VEGETABLES, EVEN HOT DOGS OR SHRIMPS

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.

Instructions for Use

- Place the pasta into the Pasta Cooker.
- Fill the Pasta Cooker with boiling water.
- Close the Pasta Cooker with the self-straining lid and thermal lid.
- For cooking times please follow guidelines below.
- Always wear kitchen gloves when removing the lid. Steam might be escaping from the Pasta Cooker.
- Remove the thermal lid and drain off the water with the selfstraining lid.



Cooking Guidelines

	Quantity in grams	Water (in ml)	Cooking time
Pasta	250	500-600	8-15 mins
Shrimp	240	300-400	11-15 mins
Ravioli	200	500-600	8-12 mins

CARE AND CLEANING INSTRUCTIONS:

- Do NOT use abrasive cleaners or sharp utensils to clean this appliance.
- Clean-up: hand wash in warm, soapy water, rinse and towel dry. Do not clean with metal pads, steel wool, scouring pads or abrasive cleaners.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.

Express Pasta Cooker к704

Instructions for Use

Please read and retain these instructions for future reference

v001: 16/03/22

Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	<u></u>	<u></u>
Type of Plastic	Polypropylene	Polystyrene
Commonly used for	Microwaveable food containers, yoghurt pots, butter tubs, disposable plates and cups	Insulation boxes, water cups, protective packaging inserts, take away containers
Notes	Commonly recycled and collected from household recycling bins (packaging tape itself not recyclable but does not interfere with cardboard)	Not commonly recycled but waste management centres will recycle it.

At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.