

# Rechargeable Crystal Touch Lamp

K796 v01: 06/05/22

Please read and retain these instructions for future reference



## Dimensions

(H) 26 x (W) 12 x (D) 12cm

- 3 DIFFERENT COLOUR SETTING - WARM LIGHT/NATURAL LIGHT/READING WHITE
- USB RECHARGABLE
- TOUCH OPERATED
- LED BULB INCLUDED IN THE LAMP (NOT REPLACEABLE, MAX. SERVICE LIFE 20,000 HOURS)
- DIMMABLE
- BASE – 8.5CM

## User Instructions

### Power connection:

Insert the USB receiver into the energizing port and plug the other end into the power port.

This product is suitable for general USB interface line, which can be connected to mobile power supply, computer, ordinary and vehicle-mounted power supply, etc.



- CHARGING TIME: 1-2HOURS
- USING TIME BETWEEN CHARGES: 8-10HOURS

Touch the switch to turn on the light and switch the light colour, long press to brighten or reduce the brightness. (Subject to the position of the touch mark). - short press to change light colour, long press for dimmable brightness.

Keep your finger on it and it will switch to dimmer mode

### Caution

- Luminaires should be used in a cool and ventilated environment.
- When cleaning a lamp, wipe the surface of the lamp with a wet paper towel or cotton cloth and wipe it again with a dry cloth.
- Do not use strong corrosive liquids to wipe the lamp, otherwise it will cause discoloration or damage.




## Common Troubleshooting

- **The light is not on** (make sure the light is powered on or the USB plug is tightly inserted) - Charge the lamp
- **The light touch switch is invalid or damaged and insensitive.** (check whether there is an external force to shift the light touch spring or whether the light is powered or not).
  - ① Check whether the lamp is live.
  - ② Remove the bottom four screws,  
Align the internal contact spring to the contact part and reinstall the screw.
- Even if the lamp is not frequently used, please charge it every once in a while to avoid the irreversible loss of capacity or damage caused by the storage of the battery voltage too low for a long time.

## DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – Contains the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Please Specify (includes ABS, Nylon)
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

UK  
CA

CE



# The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU  
 Tel: 0844 4824400\*, Fax: 01279 756595  
[www.coopersofstortford.co.uk](http://www.coopersofstortford.co.uk)  
 EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France  
 Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access.  
 Please check with your telephone supplier.