

Solar Light Up Owl Stake

K895 v001: 09/05/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife

ALWAYS POSITION IN DIRECT SUNLIGHT



Dimensions

(H) 43 x (W) 10 x (D) 8cm

- DECEPTIVELY REAL AND LIFE SIZE
- HIGH QUALITY FINISH
- WATERPROOF
- SOLAR PANEL ON THE SIDE, BY THE ROCK THE OWL IS STANDING ON

Battery required: 1x Ni-MH AAA 600mAh 1.2V Battery (included)
1 x Warm White LED Light (not replaceable)

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.
Connect the spikes with the top part by twisting them together.

Before using first time

CHARGING AND OPERATION:

1. Set button which is located underneath the BATTERY BOX to "ON" position for charging and charge by placing it under direct sunlight for at least 8 hours.
2. The light will work automatically. It will charge under direct sunlight during the day time and illuminate at night.

NOTE: In order to verify that the button is correctly in the "ON" position, cover the solar panel with your hand and light should turn "ON" automatically.

Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically



**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
Please check with your telephone supplier.

To easily insert stakes into the ground, it is recommended to wet the ground first. To avoid damaging garden stakes when inserting into the ground, select a spot in soft, rock-free soil. Insert the base of the stake first then gently insert the rest of the stake into the base. DO NOT push directly against the solar cell or the ornament housing containing the actual LED light.

Care and Maintenance Recommendations

1. Clean solar panel with a soft sponge every couple of weeks.
2. Make sure all connectors are still tight and no water getting in.
3. If solar product does not light up after it has been used for around 8 – 12 months, replace the rechargeable batteries as they may be weak or worn out.

BATTERY REPLACEMENT:

Step1: The battery compartment is located underneath the solar panel. Remove battery compartment cover by using a small Phillips head screwdriver (not included) .

Step2: Remove the exhausted battery and install 1x AAA” 1.2v 600Mah, Ni-MH, Rechargeable according to the polarity symbol indicated on the battery compartment. Open the compartment carefully and ensure that welding wires inside the battery terminals are not damaged.

Step3: Replace battery compartment cover, screw it back into position and make sure it is properly sealed.

Step4: Charge battery for at least 8 hours in direct sunlight.



BATTERIES

- Keep batteries away from children and pets.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer’s safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.




Solar Light Up Owl Stake K895

Please read and retain these instructions for future reference

Instructions for Use

v001: 09/05/22

Code & Symbol	
Type of Plastic	ABS
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
Please check with your telephone supplier.