

**Dimensions**

(H) 195 x (W) 90cm

- SUBTLE PATTERNED PANEL WITH AIR BRUSH COLOUR HIGHLIGHTS
- CHRISTMAS VILLAGE SCENE WITH SANTA AND SLEIGH
- 15 LEDs (not replaceable)
- SETS THE SCENE FOR THE FESTIVE SEASON
- READY TO HANG WITH TENSION ROD INCLUDED
- COMES WITH TENSION ROD TO HANG IN THE DOORWAY EXTENDABLE FROM 63-110CM
- CURTAIN MEASURES 90X195CM
- MACHINE WASHABLE AT 30° (REMOVABLE LIGHT WIRE)
- 2x AA batteries required (not included)

**This is not a toy!****Not suitable for children under 3 years.****The product may contain small parts.****ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

- For indoor use only as decorative curtain panel or wall hanging.
- This seasonal product is not intended for permanent use.
- DO NOT place this product near heaters, fireplaces, candles or other sources of heat.
- Please read and follow the instructions for light placement below.
- This product is NOT A TOY and should NOT be operated by children. Children should be supervised whenever this product is in their presence.
- Remove light string before washing. DO not use in or near water with lights attached.

Parts

1x 15 LED light bulbs chain. (2 x AA batteries required. Not included)

1x plastic rod (4 parts)



1x tension rod

1x fabric panel



COOPERS
OF STORTFORD

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France


Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.

Assembly instructions

- Determine the back of the panel (the care and fibre label is sewn on the back of the panel).
- Refer to the diagram. The number 1 represents the bulb at the end of the string. The number 15 represents the bulb nearest the battery box.
- Working from the back of the panel, begin with the end light and start inserting the tip of the bulb through the knit hole. The hole looks like a button hole in fabric. Push the lights all the way through the curtain.
- Follow the number sequence in the diagram, inserting all bulbs into the proper holes.
- Use tension rod to hang on top at the top of the panel (rod pocket on panel), and adjust the size of tension rod to fit the door/window.
- Assemble the plastic rod (4 small parts) to become one long plastic rod. Insert this into the pocket at the bottom of the panel.
- Once you hang the panel, you may find it necessary to slightly untwist some of the wire on the light so make the panel hang flat and smooth.
- Once in place the battery pack with batteries inserted can be placed into the small pocket at the back side in the middle of the panel.



Inserting batteries observing correct polarity



Inserting the plastic rod



Battery box pocket

**ALWAYS USE ALKALINE BATTERIES.
DO NOT USE LITHIUM BATTERIES.**

Care & Maintenance

Machine washable at 30 degrees. **IMPORTANT: Remove string lights before washing.**

**COOPERS
OF STORTFORD**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.

Please check with your telephone supplier.


BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Code & Symbol	 OTHER
Type of Plastic	Polyester
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.

