

SOLAR HEDGHOG WITH SUCCULENTS

Item codes: M532

Instructions for Use

v001: 24/01/24

Please read and retain these instructions for future reference

GAINSBOROUGH

Garden & Wildlife

ENGLISH INSTRUCTIONS

Power Details:

AA battery (REPLACABLE, RECHARGEABLE)

Dimensions: H14 xW23 xD12cm.

1xAAA 300mAh 1.2V.

Each Item included 7 x Warm White LED Lights.

only use NIMH rechargeable batteries as applicable.

CHARGING AND OPERATION:

1.Set button which is located on the top of item to "ON" position for charging and charge by placing it under direct sunlight for at least 8 hours.

2.The light will work automatically. It will charge under direct sunlight during the daytime and illuminate at night.

NOTE: In order to verify that the button is correctly in the " ON " position, cover the solar panel with your hand and light should turn "ON" automatically.

ON/OFF

IMPORTANT:

1. Placed the item in an area where it can get direct sunlight.
2. Leave the button to "ON" position.
3. Select an outdoor location away from other light sources at night, such as streetlights. It may cause the product not to turn on automatically at night.
4. Duration of light depends on solar product's level of sunshine exposure, geographical locations, weather conditions and the hours of daylight.

WARNINGS AND SAFETY INSTRUCTIONS:

WHEN USING ANY APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED:

- READ ALL INSTRUCTIONS BEFORE USE.
- FOR DOMESTIC OUTDOOR USE.
- NOT FOR COMMERCIAL USE.
- BEFORE USE, CHECK THOROUGHLY FOR ANY DEFECTS AND DO NOT USE IF DEFECTS ARE FOUND. TAKE CARE NOT TO DROP THE APPLIANCE AS HEAVY IMPACTS MAY CAUSE INTERNAL DAMAGE.
- THE USE OF ANY ACCESSORY OR ATTACHMENTS NOT RECOMMENDED BY COOPERS OF STORTFORD MAY CAUSE INJURIES AND INVALIDATE ANY WARRANTY YOU MAY HAVE.
- DO NOT PLACE ON OR NEAR HEAT SOURCES.
- DO NOT COVER THE ITEM IN ANY WAY WHEN IN USE AS THIS MAY CAUSE OVERHEATING.
- DO NOT USE THIS APPLIANCE FOR ANY OTHER USE THAN THE INTENDED USE IT IS DESIGNED FOR.
- DO NOT LEAVE SWITCHED ON OR UNATTENDED.

BATTERY WARNING:

KEEP OUT OF REACH OF CHILDREN. IF SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY SEEK IMMEDIATE MEDICAL ATTENTION.

- INSTALL BATTERIES IN ACCORDANCE WITH ITS POLARITY SYMBOLS. DO NOT FIT BATTERIES IN REVERSE.
- DO NOT SHORT CIRCUIT THE BATTERY TERMINALS.
- REMOVE THE BATTERIES IF LEFT FOR LONG PERIODS.
- **KEEP BATTERIES AWAY FROM CHILDREN AND PETS.**
- DO NOT MIX USED AND NEW BATTERIES.
- **NEVER DISPOSE OF BATTERIES IN A FIRE.**
- BATTERY DISPOSAL, SPENT OR EXPIRED BATTERIES MUST BE DISPOSED OF AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER'S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS.

CARE AND CLEANING INSTRUCTIONS

- ALWAYS SWITCH OFF AND REMOVE BATTERIES BEFORE CLEANING.
- DO NOT IMMERSE IN WATER.
- DO NOT USE ABRASIVE CLEANERS OR SHARP UTENSILS TO CLEAN THIS APPLIANCE.
- WIPE SURFACES WITH A SOFT DRY CLOTH. DRY THOROUGHLY BEFORE FURTHER USE.
- STORE THE APPLIANCE IN A COOL, DRY PLACE

MAINTENANCE AND TROUBLESHOOTING:


1. Make sure the switch is set to "ON" position.
2. Keep the solar panel clean.
3. Battery 1pc AAA " 1.2V 300mAh, Ni-MH, Rechargeable, replaceable.


Battery replacement:

1. Unscrew the battery compartment cover by using a Phillips head screwdriver (not included).
2. Remove the exhausted battery and install 1 pc new AAA rechargeable battery according to the +/- polarity as beside image. Open the compartment carefully and ensure that wire inside the battery terminals is not damaged.
3. Replace battery compartment cover, screw it back into position and make sure is properly sealed.

BATTERY DISPOSAL

- SPENT OR EXPIRED BUTTON CELLS MUST BE DISPOSED SAFELY AWAY FROM CHILDREN ACCESS AND RECYCLED IN COMPLIANCE WITH YOUR LOCAL AUTHORITY REGULATIONS.
- FOLLOW THE BATTERY MANUFACTURER'S SAFETY, USAGE, AND DISPOSAL INSTRUCTIONS.

<p>DISPOSAL</p> <ul style="list-style-type: none"> • Coopers of Stortford use recyclable or recycled packaging where possible. • Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations. • At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal. 	
--	---

Code & Symbol	
Type of Plastic	Please Specify (includes ABS, Nylon)

CUSTOMER SERVICES:

Distributed by / Verteilt durch / Distribué par.

UK: The Enterprise Department Ltd.
11 Bridge Street, Bishops Stortford, Herts, UK, CM23 2JU
Tel: 0330 331 0300

NI/EU:
D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France
Tel: (+44) 1279 701269

