



Air Fryer Disposable Paper Liners Set of 50 Square



Thank you for purchasing our Air Fryer Disposable Paper Liners Set of 50 Square.

We hope you will be happy with our purchase.

Features:

- Help reduce sticking
- Make cleaning easier
- Crisp up food while reducing the chance of burning

Care Instructions:

- Never use the paper liner alone in the air fryer
- Always preheat your air fryer making sure to keep the lid off
- Ensure the paper liner is adequately weighted before you add your food to the air fryer
- Ensure your paper liner is perforated before using it to line your air fryer to provide ventilation during cooking
- Ensure your paper liner is the correct size for your air fryer. The paper liner should completely line the base of the air fryer but not overhang the basket's sides
- Never substitute the paper liners with paper towels as they cannot withstand the heat.

How to use:

1. Connect your appliance to the power source and switch it on to pre-heat
2. Be alert on the preheating and temperatures to match your ingredients
3. Remove your air fryer basket and tray (if any)
4. Place the liner on the bottom of the air fryer basket
5. Place your food

WARNING!**Note:**

Check the measurements of the bottom of your air fryer basket in order to select the appropriate size of liner.

Important:

To help air circulation and provide even cooking, ensure that the liner is sitting flush in the basket with no crumpled edges, no food overhanging the liner. Anchor the liner securely with food to prevent it from being lifted or dislodged by internal air circulation.

Ensure that the liner does not overhang the basket or come into contact with the heating elements.

Caution:

Do not preheat the air fryer with the liner inside. Take special care when removing the basket and adding the liner as it will be hot. Use utensils /oven gloves to avoid risk of injury.

The liner takes up to 428 degrees F or 220 degrees C for a maximum period of 20 minutes of cooking time. If the food requires longer than 20 minutes, carefully open the air fryer to allow excess heat to vent and shift food around the liner. Use utensils /oven gloves to avoid risk of injury.

Ensure the liner is securely anchored again and resume cooking, not exceeding another period of 20 minutes.

