



Perfect Microwave Sandwich Maker



Thank you for purchasing our Perfect Microwave Sandwich Maker, an easy and clean way to grill food and prepare toasted sandwiches.

Our Perfect Microwave Sandwich Maker uses susceptor material to cook at temperatures of 240°C and above in 2-3 minutes.

It's ideal for cooking meat, vegetables, pizza and sandwiches at microwave speed while keeping all their flavour and quality.

We hope you will be happy with your purchase.

SAFETY AND USE GUIDELINES:

- For microwave use only. Not suitable for use in conventional ovens.
- For use with microwaves of 700-900W
- **Do not use in a microwave oven with a power higher than 900W**
- Before first use, wash the product using a soft cloth and ensure it is dry before using.
- Never use abrasive or scouring pads as these may damage the grill plate surfaces.
- Do not use heavy detergents, bleach or other corrosive cleaning agents.
- Remove handles before washing.
- If using in a dishwasher, place carefully in the dishwasher's top rack. Dry the grill plates immediately after washing. Take extra care to dry the inside edge.
- If item is or appears damaged, do not use.
- Ensure the silicone handles are dry, clean and free of food particles before pre-heating.
- Always use heat-resistant gloves when removing the Perfect Sandwich Maker from the microwave, use both hands and keep the item level to avoid any spillages.
- Always ensure that the plates are securely attached to the silicone handles.
- Should the item produce sparks, electrical arcs or show any sign of fault, immediately stop using.

- Do not place flammable liquids, corrosive chemicals or non-food items in the Perfect Sandwich Maker.
- Always preheat the Perfect Sandwich Maker in the microwave for 30 seconds at the maximum power of 900W.
- **Never preheat the Perfect Sandwich Maker for more than 1 minute**
- Only use in a microwave that has a functioning turntable, ideally of 24.5cm in diameter. Ensure that the Perfect Sandwich Maker can rotate freely when in use.
- Do not use the grill or convection function on the microwave when using the Perfect Sandwich Maker.
- Allow item to cool between uses to avoid overheating and damage
- Never use the Perfect Sandwich Maker for more than 20 minutes at the time.
- Check cooking times required by the recipe.
- Always allow item to cool completely before washing.
- Never overfill the Perfect Sandwich Maker or add liquids that may overflow.
- Distribute food evenly in the Perfect Sandwich Maker and keep an eye on the product whilst in use.

USING THE PERFECT MICROWAVE SANDWICH MAKER

- 1) Pre-heat the Perfect Sandwich Maker for no more than 2 minutes at the microwave setting before adding food. Take care when removing from the microwave as the Perfect Sandwich Maker will be hot.
- 2) Where possible, use an insulation mat when placing the Perfect Sandwich Maker on a worktop to avoid potential damage to surface.
- 3) If required, brush food lightly with oil for better results. Avoid drips and spills.
- 4) Place food items evenly on the lower plate. Place the upper plate on top and lock into place with the silicone catches.
- 5) Place in the microwave on a flat surface.
- 6) For recipes that require the food to be turned, remove the Perfect Sandwich Maker from microwave and remove any excess liquids before returning to microwave.
- 7) Remove from microwave with care, using heat resistant gloves. Use both hands and keep the grill horizontal to avoid any potential spillages.
- 8) Carefully undo the silicone catches and remove food. Avoid using metal utensils as these may damage the hot plate.
- 9) Enjoy your meal!

Please note:

Cooking times may vary depending on your microwave.

It is important to know how your microwave works and to check the food every now and then, especially the first few times, shortening or lengthening the cooking times as necessary

Here's a quick guide to timings after preheating the grill for 2 minutes, based on a 900W microwave - timings will vary.

- Toasted cheese and ham sandwich – 3 minutes

- Beef burger – 5 minutes 30 seconds
- Sausages - 5 minutes
- Veggie burger – 5 minutes
- Salmon fillet – 2 minutes
- Chicken breast – 8 minutes
- Asparagus – 5 minutes

Microwave safe; heat-resistant up to 240°C.

Materials: 100% platinum silicone and non-stick coated steel – heating element is ferrite silicone.

Non-stick coating is BPA and PFOA free.

