# **Set 4 Solar Up & Down Fence Lights**

K846 v001: 13/05/22

Please read and retain these instructions for future reference



**ALWAYS POSITION IN DIRECT SUNLIGHT** 



#### **Dimensions**

(H) 10 x (W) 7.3 x (D) 3cm

- EACH SOLAR LIGHT HAS 2 WARM WHITE SMD LED'S (NOT REPLACEABLE) AND INTEGRAL SOLAR PANEL
- NO MESSY OR TRAILING WIRES
- COMES WITH WALL FIXINGS
- AUTOMATICALLY ILLUMINATES AT NIGHT
- PLACE IN A SUNNY SPOT
- LIGHT A WALL, FENCE OR SOME STAIRS

Required: 1x AA 1.2V 400mAh Ni-Mh battery per light (included) (not replaceable)

### **ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:**

Unpack the components carefully. Please check all parts have been removed from the packaging.

# Before using first time


Allow lamp to charge for at least 8 hours in full sunlight with the ON/OFF switch in the ON position. The ON/OFF switch is usually located below or next to the solar panel. Once the batteries are fully charged, set the ON/OFF switch to ON. If the lamp does not turn on after dark refer to Maintenance section.



## Find an ideal Place for the Solar Light.

Place the solar light in an area where it will receive direct sunlight for at least 8 hours per day. The number of hours the light will illuminate is directly proportional to the hours of sunlight it receives. If the light is placed in a shaded area, it will not be able to fully charge and its illumination time will be limited. Do not place the light near other outdoor lighting like porch or streetlights. These may fool the sensor and keep the light from coming on, or cause it to turn off automatically

#### Installation



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400\*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.

# Set 4 Solar Up & Down Fence Lights к846 lr

Instructions for Use

Please read and retain these instructions for future reference

001:13/05/22

#### **Care and Maintenance Recommendations**

- 1. Clean solar panel with a soft sponge every couple of weeks.
- 2. Make sure all connectors are still tight and no water getting in.
- 3. If the light stops working after it has been used for a long time (approx. 12 months), the battery may be passed its lifespan. Turn off the solar light and open the cover of the battery compartment to change the battery. Battery specification: 1 x AA 1.2V 400mAh Ni-MH rechargeable.



#### **BATTERIES**

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

#### **DISPOSAL**

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.



• Plastics, polybags – this is made from the following recyclable plastic.

Code & Symbol	OTHER
Type of Plastic	ABS, PC
Commonly used for	CD's, crisp packets, various flexible packaging, baby bottles, sunglass lenses
Notes	Not often or widely recycled

• At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



The Enterprise Department

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU Tel: 0844 4824400\*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

\*UK Calls cost around 7 pence per minute plus your telephone company's network access. Please check with your telephone supplier.